



1. Locate footprint of cabinet.
2. Locate line 34" or more from ceiling (8' long).
3. Locate stud centers (studfinder).
4. Center ledgerboard between ends of 8' line. Transfer stud centers to ledgerboard.
5. Drill 1-1/8" and 3/8" holes in ledgerboard.
6. Put ledger back on 34" line, centered between 8' ends. Drill through sheetrock and stud with 1/4" drill. Go deep.
7. Lagbolt to wall a minimum 4 good solid lags.
8. Set upper cabinet on ledger. Drive 3" deck screws through nailer into stud. Try to get 2 into a stud.
9. Put 4 deck screws through bottom and into ledger at 45° angle.
10. Position bottom cabinet and screw to wall if desired.